

INSTRUCTIONS

essencia

EXPRESS

50L 2KW BOILER with THERMOSTAT



LARGE 5-50L BOILER

10-110°C THERMOSTAT

STILL • MASH TUN

SPARGE HEATER • WORT BOILER

304 STAINLESS CONSTRUCTION

304 SS TAP

LARGE 5-45L BATCH

2,000 WATT

10 AMP 220-240 V


DOMED LID WITH 47mm HOLE

INSTRUCTIONS

1. Make sure the tap on the boiler is closed. Pour your liquid into the boiler. Do not fill higher than 45L.
2. Plug in the boiler, and turn the thermostat to set the thermostat to the desired temperature. It is recommended to set it to no higher than 90 Celcius during the heating phase.
3. Switch the 2000 Watt element to the on position. The green light will show and the red light will be off.
4. The thermostat will automatically switch off the element once the desired temperature is reached.



The concealed element has a safety cut-out switch which will switch off the element if the unit overheats. If this happens, switch off the unit and allow to cool down. Check there is sufficient liquid in the boiler, and that the inside base of the boiler is free from burnt-on matter. The unit will automatically rese. Then switch the unit back on.



IMORTANT SAFETY NOTES

DO NOT switch on the boiler if there is no liquid covering the base.

DO NOT switch on your boiler without liquid in it. Do not allow it to boil dry. There is an automatic cutout switch underneath that will rest itself once the unit has cooled down.

The boiler and condenser will become VERY HOT. DO NOT touch them with bare skin. Switch off and allow components to cool down before handling them.

